

# KWIK CLEAN 3<sup>®</sup>

## Instructions for Assembly



Endorsed by



## Instructions to assemble KWIK CLEAN 3<sup>®</sup> pre-rinse equipment:

1. Shut off the water supply.
2. If you are replacing the hose, loosen the hose from the top of the riser by turning the hose in a counter-clockwise direction.
3. If you are replacing an existing handle, loosen the handle from the hose by turning the handle in a counter-clockwise direction.
4. Install the larger washer between the handle and the hose, and turn the handle into the hose in a clockwise direction until hand tight.
5. If you are replacing a pre-rinse nozzle, hold the handle firmly and turn the existing nozzle in a counter-clockwise direction to remove.
6. Install the smaller washer between the handle and the Kwik Clean 3<sup>®</sup> nozzle and tighten by turning the nozzle in a clockwise direction.
7. Slowly turn the water back on, check for leaks and tighten further if necessary.



## Additional Pre-Rinse Products Available:

- The Pivot Pro™ swivel connector, installed between the handle and hose, allows for greater cleaning flexibility and better ergonomic performance for the washer.
- Nut Driver/Tip Changer for replacing tips
- Replacement tips: all tips are easily removable, cleanable or changeable to offer the best performance for each customer's specific requirements.



### Available tips are:

- Flat V spray fan tips with angles of 5 degrees, 10, 15, 20...up to 110 degrees.
- Solid-stream, jet spray tips.
- Tri-Tip for fast cleaning with splash control.
- Flow rates from 0.3 gpm to over 2.0 gpm.
- Full cones, hollow cones or tips with an angle built into the tip itself.



Fan Spray, Solid Stream,  
Tri-Tip (top to bottom)

*Last Updated: August, 2011*



### USA Headquarters

2801 Baglyos Circle ♦ Bethlehem, PA 18020

Phone: (484) 893-5080 ♦ Fax: (484) 893-5099 ♦ Toll Free: (877) STRAHMAN

strahman@strahman.com ♦ www.strahmanvalves.com